



1	Clear register IV (Accumulator/Totaliser)	13	Prevents automatic carriage return after multiplication
2	If vertical, the right part of register II will not be cleared	14	Prevents automatic clearance of the multiplication register
3	Determines whether sub results will be added (=) or subtracted (~) in register IV	15	Clear keyboard
4	Stops a subtraction when the current digits has been calculated	16	Clear register II
5	Starts a division	17	Clear register I
6	Immediately stops a division	18	Add or subtract multiplication result in register I
7	Set upward the counter adds 1 for each addition and subtracts for a subtraction. Set downward (- position) the counter always subtracts 1	19	Prevent automatic clearance of the keyboard
8	Set to – the counter reverses, i.e. subtracts 1 for each subtraction and adds 1 for each addition. 7 overrides 8.	20	Position the carriage and enter the dividend from the keyboard. Digits are entered on the right side of the keyboard
9	Add and Subtract keys	21	Back Transfer register I to the multiplication register
10	Carriage stepwise movement	22	Connect register IV (Totaliser) to register I
11	1 <sup>st</sup> push: Enter the multiplicand in the multiplication register 2 <sup>nd</sup> push: start multiplying with the multiplier in the main keyboard	23	Pull to prevent automatic clearance of register I in multiplication and register II in a division
12	Clear multiplication register		